

# Real Stone Tall Triple Fountain Kit Installation Manual



For use with Tall Triple Stone Column Fountains with Drilled Achelous Basin Cover and Splash Apron Instructions

# Included in this Kit:

3 Stone Fountains

Polished Pebbles

2 Grate Halves — Pump Access Cover •

Triton Discharge Assembly and 3-way Splitter

Fountain Pump



Blue Thumb makes installation of your triple column stone fountain kit easy by following these instructions.

Subscribe to our YouTube channel, **BlueThumbINC**, for related informational videos.

3 pre-cut tubing pieces
Flow Control Valves
Meldad Regin

Molded Basin Reservoir



# **STEP 1** Choose Location for Basin

**1a** Locate your fountain near your preferred viewing area where both water and electricity services are accessible. Be certain to avoid underground utilities.

**1b** Clear the area and prepare to excavate by tracing the fountain basin using marking paint.



Be certain to avoid underground utilities. If uncertain call your utility company or Miss Dig.

# **STEP 2** Excavation of Basin Area



2a Using a shovel dig 90 degrees into the ground, slightly wider and deeper than the basin, so it will sit firmly on the ground. 1½"- 2" below grade allows you to slope the surrounding terrain toward the basin.



2b Remove any sharp rocks or roots.



**IMPORTANT** Level the bottom of the hole across the entire basin, add sand or small gravel if needed. **Tamp** to ensure no settling occurs after installation. Check again to make sure the center is level with the edges.



### STEP 3 Set Basin in Place

Position the basin within the hole. Make sure the pump opening in the grate is orientated near electrical service.

If installing the splash apron, set basin in the hole and verify that the basin top is level and approximately 2" below grade.



Using a level, ensure the fountain basin remains level side to side. The basin should sit solidly on the compacted and leveled ground below. Hanging the lip of the basin on the surface can cause the basin center to buckle.







# **STEP 5** Backfill

Backfill around the box and soil using excavated soil or self-compacting material, such as sand or pea gravel. When using excavated soil be sure to regularly compact with a tamper.

If your basin included a cardboard cover leave it in place while you backfill to prevent soil from falling into the basin.

Note: The more solid the soil is around and below the reservoir, the less shifting over time from settling and rain.

# **STEP 6** Slope and Smooth Ground

Using a shovel, create a gentle slope or berm starting approx. 18" from the edge of the basin. Slope the ground toward the basin lip to help direct any water runoff back into the basin, minimizing water loss. Clear any rocks and tamp to smooth.





### Optional Auto Fill Kit Install

If a Blue Thumb Elite Auto Fill Kit is being incorporated, you may bury your water supply line and make any Auto Fill connections at this time.



Kit Item: #ABDAUTO

# **Important Before Filling your Basin**

Once Achelous Basin is in place, clean basin area of any lose dirt.

Remove cardboard and vacuum out any dirt that may have fallen into the basin then wipe clean before adding water. Keep that pump happy with a clean basin full of clear water!

You may fill your basin with clean water at this point to stabilize the basin, or you may wait until your fountains are in place.









If plume lighting has been purchased, read Page 5 now, otherwise skip to page 6.

### **Determine Fountain Placement**

Before continuing, consider placement of the fountains. They can be as close together or as far apart as you like, taking care not to place fountains too close to basin edges, as this may cause potential water loss from splashing. Also, leave the pump access clear for maintenance. You may mark fountain placement with stones for drilling.

## STEP 7

### **Grate Preparation**

You may remove the grate for drilling. Use a 1½" hole saw to drill holes in the grates for the fountain tubing to feed up from the basin and into your fountains.

**Note:** If the basin has a sediment screen in place, use a knife to cut the screen before drilling.

**DO NOT** drill in the marked areas in the image on the right. The molded support columns in the basin will be located under these points.

Additionally, notice that the two halves of the installed grate should meet over the wider set of support columns for greatest grate strength.

An additional PVC center support may be included for added stability.

# STEP 8

### **Connect Pump Plumbing**

8a The tubing is in fixed lengths of 8', 7', and 5'. These lengths correspond to the height of the water features with the longest hose going to the tallest fountain. On the Triton there is a 3/4" expander piece of tubing over the barbed connector. You will slide the 1" tubing over this 3/4" tubing. It's a tight fit but is easy if you heat the end of 1" tubing in hot water to make it pliable.

**8b** Attach 90° discharge elbow assembly to the pump.

**8c** Slide the Triton 3-way splitter valve and tubing onto the discharge assembly. Tighten the hose clamps.





# **Proceed to Step 9 if Plume Lighting was Not Ordered**



### **Internal Plume Lighting** Add-on Kit

If your Triple Stone Fountains are pre-drilled for the optional IllumiGlow® Fountain Plume Lighting Kit, follow the instructions provided in the lighting kit before returning to STEP 8.












**Basic RGB LED Plume Lighting Set Up –** See lighting kit for full instructions

**Note:** When installing lighting with your kit your tubing will be 3/4" instead of 1" and you will not need tubing expanders when attaching to the pump assembly.

> The fountains can be shimmed to balance




STEP 1 Drop the Light Cord (4) from the top of the fountain to the bottom and pull through until set.






STEP 3A (Fountain top) Connect the Tubing (3) to the Barbed Connector (2) at the bottom of the RGB LED Light (1). You won't need o-rings, the lights will hold the tubing in place.





STEP 4 At the fountain base, pull the Light Cords (4), lay above the grate screen, and direct them to the Splitter. Repeat with other two fountains.







Triton Flow Valve Assembly









# **STEP 9** Install Splash Apron

If installing a Splash Apron, do this prior to fountain installation.

### **Cut the Splash Apron**

**9a** Measure to find center on the sheet of liner, then measure 20" in each direction from the center point.

**9b** Cut out a 40" x 40" circle out of the splash apron center. This size will leave 4 inches all around to tuck under the basin grate.

### Lay the Splash Apron

**9c** Lay the splash apron over the open basin. You will want to have the pumps and plumbing set in the basin, and in position to thread hoses through the 2-piece grate once placed.

**9d** Set screened grates over the liner. Adjust until positioning of the splash apron is secure and satisfactory.

NOTE: Normal evaporation is about 1-2" weekly, however, that is dependent on your region. Many factors including humidity, rainfall, wind, and splash will determine exactly how frequently you need to refill.



## **STEP 10**

### **Install PVC Support and Pump Assembly**

Place the grate half with the pump access.

If included in your kit, install the PVC Support Column under this grate in the center of the basin. This support provides additional strength with heavier fountains.

Place pump and tubing in the basin. Keep the pump positioned as close to the pump access opening as possible for best accessibility.





# **STEP 11** Pull Tubing Through

11a During installation, make sure the plumbing has no kinks or twists, which will cause a reduction in water flow, and possibly no flow at all, in that particular line.

**11b** Pull all three tubing pieces through the grate about 12" or so, noting which is longest and which is shortest. If purchased, put the screen over the tubing cutting holes to match the drilled grate holes.

# **STEP 12** Fountain Setup

**12a** Position one of the column fountains near its designated hole in the basin, laying it down with the bottom close to the hose. Feed the correct length of tubing through the bottom of the column, ensuring that the end extends 1-2 inches past the top to make securing the tubing with the O-ring easier.

**12b** Carefully stand the column upright, ensuring the hose is not pinched underneath. Any excess tubing can be fed back into the basin.

Repeat process with the remaining column fountains.



# Step 13 Secure Tubing with O-Ring

**13a** Slide the o-ring over the tubing extending from the top.

**13b** Push excess tubing back into the basin so it sits just below the top of the fountain surface. The o-ring will hold the tubing in place.

**13c** The tubing should just extend to the inside of the fountain without being visible.



# Step 14 Testing & Flow Adjustment

If you haven't already added water to the fountain basin, add water until the basin is filled to the bottom of the grates. Plug in the pump cord to test your fountain.

Set the water flow and plume height by adjusting the valves with the provided red valve key attached to your pump assembly. Use the included plastic shims to level the fountains for even water flow over the columns.





If the height of the plumes is still lacking, use the 3 pieces of 1" x ¾" clear vinyl and insert them into the ends of the fountain hoses. This will increase the height of the water plumes.

Splash should be kept to a minimum to avoid excessive refilling. Our optional Auto Fill Kit, (#ABDAUTO) is used to keep the water level topped off with minimal maintenance checks.



# **Finishing**

Cover your basin with Polished Pebbles and surround with your favorite foliage. Avoid placing soil or bark on the grate because it may fall through the screen into the basin and affect water flow.

Enjoy!





Auto Fill Kit #ABDAUTO



Muck Buster® #PB2682



Algae D-Solv® #PB2002

### **Maintenance**

### **General Fountain and System Maintenance**

- It is OK to run pump continuously 24/7, or you may choose to connect it to a timer.
- Regularly check the water level in the basin. Never allow the water to drop below the pump, as this can lead to pump failure.
- Fill evaporated water as necessary or considering installing an Auto Fill Kit #ABDAUTO.
- Add Muck Buster® #PB2682 every couple of weeks to the basin to ensure muck doesn't build-up over time and clog the pump.
   3 tablets treat 500 gallons of water.
- If algae forms on columns, brush off and use Crystal Clear®
   Algae D-Solv® #PB2002 to quickly clear organic debris and
   remove odors. 1 ounce treats 360 gallons.

### Winterizing:

- If you live in a climate that experiences prolonged freezing conditions, we recommend removing the pump from the basin.
   Place the pump in a bucket of water and store it in a place that will not freeze
- Do not drain the basin during the winter months allow the water to freeze in the basin so that the ground doesn't cause the basin to rise or "pop up" from expansion of the freezing soil around it.
- Our Rock Columns are manufactured to withstand freezing conditions and can be left outside during the winter months.
   There is no need to cover the Rock Columns, but you may do so if you desire.

### **Spring Start-Up:**

- Once everything has thawed in the spring we recommend draining the water in the basin and replacing it with fresh, clean water. A wet/dry vacuum works well for removing water and accumulated debris.
- Reconnect the pump and plug it in.
- Add Muck Buster® to remove any remaining muck that was not able to be removed manually.

If you need replacement parts please contact us directly at 888-619-3474 or email us at sales@bluethumbponds.com.

Now, snap a picture of your completed waterfall and post it to our Facebook page at facebook.com/bluethumbinc!

www.shopbluethumb.com





