



Formal Falls® Kit

Installation Manual



Blue Thumb

For use with Small and Medium Kits
16" Formal Falls® Kit #PB1649
28" Formal Falls® Kit #PB1658

Optional LED Color Changing Light in Basin

Included in this Formal Falls® Kit:

- *Formal Falls® Stainless Spillway*
- *Formal Falls® Basin with Light*
- *Blue Thumb Pump*
- *Pump Pre-filter Sock*

- *Pump Discharge Assembly*
- *Flex Hose*
- *PVC Primer & Cement*
- *Installation Kit*



STEP 1

Prepare Base Layer for Build

Install an appropriate and suitable level of base to lay the block wall and Formal Falls® Kit.



STEP 2

Determine Plumbing Placement

Choose which Formal Falls® Basin side will be plumbed for water cycling. Close off the remaining side with provided fitting, wrapping the threads with Teflon tape to prevent leakage. Set the basin in place to begin building the back wall, adjusting for plumbing height.



STEP 3

Attach Discharge Assembly to Pump

Thread the discharge assembly provided in the kit on to the pump, making sure all PVC fittings have been primed and glued. Place the pump pre-filter sock into the basin chamber.



STEP 4

Place the Assembled Pump in Basin

4a. Place the pump into the pre-filter sock and close draw strings. **4b.** Attach discharge assembly to outlet and tighten clamp. **4c.** Pull out the power cord for proper basin placement through the notch in basin.



The Formal Falls® Basin protects the Pump & Plumbing Assembly. Decorative stones disguise the molded basin and Flex Hose. The Pump circulates water from the Basin into a Formal Falls® Stainless Weir, which cascades the waterfall down into the basin and the cycle begins again.

STEP 5

Continue Block Wall Build

Continue building the block wall to the desired falls height. We recommend that the overall height of the waterfall not exceed 24" in height. Placing the unit higher increases the likelihood of wind related water loss.



STEP 6

Attach PVC Elbow to Basin

With the basin placed against the wall, cut a piece from the included flex hose that is long enough to extend from the basin through the wall and attach a 90-degree elbow. This length will be determined by the thickness of your wall.



STEP 7

Attach PVC Fittings to Spillway Inlet(s)

7a Place the Formal Falls unit on block wall. No bridge is needed above your weir, that support is built into our Formal Falls weir.


7b Wrap Teflon tape onto the thread of the fittings attaching spillway inlet(s) and PVC elbows and T's, as provided in your specific kit.



STEP 8

Connect Spillway to Basin

Cut lengths from of the supplied flex hose for attachment of spillway inlets. Glue the assembled inlet fitting to the pump discharge assembly elbow.



STEP 9

Complete the Block Wall Build and Fill with Water

Continue constructing the wall around the front of the basin. Add decorative gravel to the top of the basin. **Be sure to leave an area void of gravel where the water will hit the anti-splash mat.** Fill the basin with water, then plug in the pump and enjoy!





Optional Lighting Kit

If you have the optional pre-installed light kit on your Formal Falls® basin, plug in and use the included infrared remote to turn on. You must point the remote at the light to operate it.



Maintenance

General Fountain and System Maintenance

- Fill evaporated water as necessary or considering installing an Auto Fill Kit #ABDAUTO.
- Add Muck Buster® #PB2682 every couple of weeks to the basin to ensure muck doesn't build-up over time and clog the pump. 3 tablets treat 500 gallons of water.
- If algae forms on spillway opening use CrystalClear® Algae D-Solv® #PB2002. 1 ounce treats 360 gallons.
- It is OK to run pump continuously 24/7, or you may choose to connect it to a timer.
- If your water flow splits, use a pipe cleaner to clear any lodged debris from the weir opening.



Auto Fill Kit
#ABDAUTO



Muck Buster®
#PB2682



Algae D-Solv®
#PB2002

Winterizing:

- If you live in a climate that experiences prolonged freezing conditions, we recommend removing the pump from the basin. Place the pump in a bucket of water and store it in a place that will not freeze. Once pump and plumbing assembly are removed the Formal Falls® spillway will drain.
- You do not drain the basin during the winter months.

Spring Start-Up:

- Once everything has thawed in the spring, we recommend draining the water in the basin by using a Shop-Vac or wet/dry vac and replacing it with fresh, clean water.
- Reconnect the pump and plug it in.
- Add Muck Buster® to remove any remaining muck that was not able to be removed manually.

Now, snap a picture of your completed waterfall and post it to our Facebook page at facebook.com/bluethumbinc!

www.shopbluethumb.com

